

ReadMe for Blank Board Serializer, v.3T106, part number 693-6430.

Utility to set the serial number of Apple Macintosh Intel and PPC based computer boards.

USAGE:

- 1) Burn the disk image to a CD.
- 2) Boot the computer pressing the option key (the Boot Picker).
- 3) Insert the disk and select it for booting.
- 4) Once the Blank Board Serializer (BBS) has started, follow on-screen instructions.

-070423